

INSTALLATION INSTRUCTIONS - DOOR FRAME COVERS

PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLING FRAME GUARDS. MATERIAL MUST BE STORED, INSTALLED, AND USED IN ENVIRONMENTALLY CONTROLLED CONDITIONS.

THE DOOR FRAME SURFACE THAT THE FRAME GUARDS ARE TO BE APPLIED TO MUST BE DRY AND FREE OF DIRT, DUST, OIL, LOOSE PAINT, WAX, AND GREASE.

ADHESIVE INSTALLATION:

- APPLY A BEAD OF ADH-50 ADHESIVE IN A ZIG ZAG PATTERN OVER THE BACK OF EACH SURFACE OF THE FRAME GUARD.
- PROPERLY POSITION THE FRAME GUARD ON THE FRAME AND APPLY PRESSURE UNTIL A TIGHT FIT IS ACHIEVED.
- REMOVE THE PROTECTIVE PLASTIC COATING FROM THE EXPOSED SURFACE OF THE FRAME GUARD

SCREW-ON INSTALLATION:

- ATTACH FRAME GUARD TO FRAME WITH NECESSARY HARDWARE. SPECIFY DRILLING REQUIREMENTS WHEN ORDERING.
- REMOVE THE PROTECTIVE PLASTIC COATING FROM THE EXPOSED SURFACE OF THE FRAME GUARD.

